



AUTOBORNE™ SEALER

MIXING CHART

SPRAY UNTIL DESIRED COLOR OR EFFECT IS ACHIEVED



6001 WHITE



6002 BLACK



6003 GREY



6004 YELLOW



6006 RED



6008 BLUE (GS)

6002	1
6001	9

6002	2
6001	8

6002	3
6001	7

6002	4
6001	6

6002	7
6001	3

6002	9
6001	1

6004	7
6001	3

6004	5
6001	5

6004	3
6001	7

6004	9
6006	1

6004	8
6006	2

6004	7
6006	3

6006	5
6002	5

6006	7
6002	3

6006	9
6002	1

6006	2
6008	2
6001	6

6006	2
6008	1
6001	7

6006	1
6008	1
6001	8

6008	9
6001	1

6008	8
6001	2

6008	5
6001	5

6008	4
6001	6

6008	2
6001	8

6008	1
6001	9

6008	9
6004	1

6008	8
6004	2

6008	7
6004	3

6008	6
6004	4

6008	2
6004	8

6008	1
6004	9

6006	3
6004	6
6002	1

6006	7
6008	1
6001	2

6006	6
6008	4

6006	3
6008	3
6001	4

6006	4
6008	2
6001	4

6006	4
6008	1
6001	5

6004	7
6006	3

6006	1
6008	1
6001	8

6008	8
6001	2

6008	2
6004	8

6006	7
6008	1
6001	2

6006	7
6002	3

6005 ORANGE

6007 LILAC

6009 PROCESS BLUE

6010 GREEN

6011 TAN

6012 BURGUNDY

Mix product numbers in listed ratios to create sealer color. Spray basecoat or pearl-flake over color on chart to test.